

Füllstandskurvenübersicht Regenwasserbehälter

Tank	00er	10er	20er	22er	31er	40er	70er	71er	72er	80er
Atlantis 2200 Liter	2,377	2,033	2,033							
Atlantis 4000 Liter	4,028	3,482	3,541	3,482	3,51		3,307			3,301
Atlantis 5300 Liter	5,544	4,994	4,994	4,994	5,274		4,989	4,906		4,768
Atlantis 7000 Liter	6,986	6,378	6,47	6,378	6,716		6,404	6,528	6,366	6,083
Ozeanis Flachtank 1700 Liter	1,768	1,463			1,714					
Ozeanis 2100 Liter	2,164	1,935								
Ozeanis 3300 Liter	3,497	3,314								
Ozeanis 4000 Liter	4,049	3,796	3,796							
Ozeanis 6000 Liter	5,95	5,725	5,725							
Ecoline 3300 Liter	3,259	2,611	2,611		2,572	2,611				
Ecoline 5000 Liter	4,865	4,155	4,155		4,155	4,155				
Oasis 4000 Liter	4,872									
Oasis 6000 Liter	6,275									
Globoline 6400 Liter	6,969	6,333	6,333							
Globoline 8300 Liter	8,278	7,645	7,645							